

PURE Help Centre

[Knowledgebase](#) > [Wireless Music Systems](#) > [I've updated my Jongo A2, the LED continually pulses red and green it is unresponsive](#)

I've updated my Jongo A2, the LED continually pulses red and green it is unresponsive

Pure Support - UK - 2014-12-15 - [Wireless Music Systems](#)

Your Jongo has encountered an error during the update procedure you can recover your Jongo A2 by doing a reset, for instructions click [here](#)