

PURE Help Centre

[Knowledgebase](#) > [All Other Radios](#) > [iDock Products](#) > [Why can't I navigate my iPod using my dock's remote after upgrading to iOS 7?](#)

Why can't I navigate my iPod using my dock's remote after upgrading to iOS 7?

Pure Support - UK - 2025-10-20 - [iDock Products](#)

Why can't I navigate my iPod using my dock's remote after upgrading to iOS 7?

Apple have changed some of their commands in the iOS 7 update and these controls no longer function. This only affects the Menu, < and > controls from your dock. All other functions will continue to work correctly and have been tested by Pure. This does not affect automotive products.